

Buildings 5 and 6 Thermostats



To Operate Manually (Without the Programmed Comfort Schedule):

Press the **HOLD** button to make the HOLD icon appear.

Then follow the four steps below:

1. To Select the Mode:

Use the **SYSTEM** button to move between the choices. OFF, HEAT, or COOL. A flame will appear for HEAT, a snowflake will appear for COOL.

2. To Select the Fan Operation:

Use the **FAN** button to move between FAN ON (fan runs continuous) and AUTO (fan runs when unit runs).

3. To Read the Room Temperature:

The large display reads room temperature until a button is pressed.

4. To Adjust the Setpoint:

In normal operation, the display shows room temperature. At the first press of the UP or DOWN button, the display shows the current setpoint. Further presses of the UP or DOWN button adjust the setpoint.

PROGRAMMED OPERATION

SETTING TIME AND DAY:

Setting the Current Time:

1. Press the **SELECT** button twice.

2. Press the UP or DOWN button until the correct time is displayed.

If you do not press the HOLD button, the thermostat will exit the time setting mode after 5 seconds.

Setting the Current Day:

1. Press the **SELECT** button to advance to the day.

2. Use the **UP** or **DOWN** button to select the correct day, press the **HOLD** button.

The Programmable Thermostat provides four periods per day (WAKE, LEAVE, RETURN, SLEEP) and two schedules per week (Mo, Tu, We, Th, Fr and Sa, Su). A separate time, heat setpoint, and cool setpoint can be set for each period and schedule. Time can only be set in increments of 15 minutes. To exit the programming mode at any time, press the **HOLD** button.

While Programming:

Slide the **SYSTEM** button to the setting you want to program; HEAT or COOL. Throughout programming, a flame or a snowflake will display to identify which mode you are in.

The **SELECT** button moves between the weekdays, (Mo, Tu, We, Th, Fr) and the weekend (Sa, Su) selections. A different schedule may be set for the weekdays and the weekend.

Programming A Weekly Comfort Schedule:

1. Press the **SELECT** button 4 times.

2. Set WAKE time and press **SELECT**.

3. Set WAKE temperature. Mo, Tu, We, Th, Fr or Sa, Su icons will appear on the display.

The current mode (flame or snowflake) will also show.

4. Press the **UP** or **DOWN** button to set the time and temperature.

5. Press the **SELECT** button when ready to move to the next setpoint.

6. Repeat steps 2 through 4

7. Press **HOLD** to exit the programming mode at anytime.

You MUST set your WEEKDAY program to access the WEEKEND program. If your WEEKDAY program is already set and you want to set or reset your WEEKEND program, push SELECT 12 times.

Modifying Your Weekly Comfort Schedule

If you choose to change any of your weekly schedule, follow the directions listed on how to change the program.

Overriding Your Comfort Schedule

There are two ways to override your comfort schedule.

Method 1 — Manual Operation

By pressing the HOLD button to turn on the HOLD icon, the thermostat will maintain the current temperature settings and ignore the comfort schedule for an indefinite period of time. The word HOLD will appear in the display. Press the HOLD button a second time and the thermostat will return the temperature programmed.

Method 2 — Temporary Override

At the first press of the UP or DOWN button, the current temperature setting will appear on the display. Pressing the UP or DOWN button again will temporarily change the setpoint as needed. At the next programmed time, the programmed comfort schedule will resume.

OTHER THERMOSTATS THAT COULD BE IN UNIT



There could be a different thermostat in the unit. This thermostat does not allow for any programming. It would be set the temp, the fan (Auto or On) and the system option of HEAT / COOL/ OFF.